




Product code: **C9G3EX004X**

Product: **Cooker**


Model: **EBS 965 IMLXX**

Product code	Serial No.	Product remark	Issue No.	Issue Date
C9G3EX004X				October 2025


Key part information	




Ref.	Part description	Product code	
		C9G3EX004X	
		Feature	Part code
1.1	Glass with frame		355VC9G11
1.2	Rear left/right hinge bracket		094886
1.4	Module support bracket		094762
1.5	Module induction right		1031855
1.6	Module induction left		1031854
1.7	Module induction support		4219G06Z
1.8	Grommet		052007
1.9	PCB		074117
1.10	PCB control		074138
1.11	PCB control support		094763
1.12	Peg		071068
1.14	Module induction central		1031864
2.2	Plug		040041001
2.3	Screw		001285
3.1	Control panel		35C9G33LEX
3.2	Towel rail handle		037424001











Ref.	Part description	Product code	
		C9G3EX004X	
		Feature	Part code
4.4	Oven insulation		030282
4.5	Rear insulation		030281
4.6	Rear panel spacer bracket		094895.1
4.8	Rear panel		4119G01Z
4.9	Upper shelter		4219G04Z
4.10	Cooling fan conveyor		1031842
4.11	Cooling fan motor	230 V 50 Hz	079072
4.12	Fan		1031843
4.13	Seal		053202
4.14	Insulation spring		035130
4.15	Cable support		103672
4.16	Terminal block	40A - 6P	051082
		40A - 3P	051083
4.18	Shim		1031812
4.19	Compartment panel spacer		040102
4.20	Left hinge		063173
4.21	Right hinge		063172
4.22	Badge		081136
4.23	Front panel		371V9G01L
4.24	Inside panel		373V9G01A
4.25	Side panel		36C9G02S
4.26	Left rear trim		51B9G05Z
4.27	Right rear trim		51B9G06Z
4.28	Rear coupler		094887
4.31	Bracket		094725
4.33	Control panel fixing trim		51B9G20Z
4.34	Cut-off thermostat		066225
4.35	Rotisserie hole plug		035097
4.38	Rear panel extension		4219G03Z
4.39	Lower shelter		4219G02Z
4.40	Terminal block support		51B9E12
4.41	Lower element cover		45K96004Z
4.42	Anti-tilt bracket		094153
4.43	Drip tray		08338900A
4.48	Lock pin		1031207
4.52	Body front panel		45B9G001G
4.53	Oven cube		4509G1EM44



Ref.	Part description	Product code	
		C9G3EX004X	
		Feature	Part code
5.1	Door glass		0329G031
5.2	Door handle		037431001
5.4	Screw		001273
5.5	Central support head door glass		069098
5.6	Lower right head door trim		069119
5.7	Lower left head door trim		069120
5.8	Inner glass		0313374
5.9	Middle inner glass		0313386
5.10	Left door hinge (female)		063164
5.11	Door hinge (male)		063171
5.12	Right door hinge (female)		063165
5.14	Upper door trim		51B9G02A
5.15	Upper left head door trim		069104
5.16	Upper right head door trim		069103
5.17	Upper left door fixing bracket		094714
5.18	Upper right door fixing bracket		094715
5.19	Rubber		040082
5.20	Upper left inner corner		069106
5.21	Upper right inner corner		069105
5.22	Side support head door glass		069097
5.23	Seal		053157
5.24	Lower door trim		51B9G21A
5.25	Left female hinge support bracket		094896
5.26	Right female hinge support bracket		094897
7.1	Shelf support		217789
7.2	Shelf support screw		001142
7.3	Oven tray		48B9G01G
7.4	Oven shelf		217785.1
7.14	Left telescopic runner		1031783
7.15	Right telescopic runner		1031782
7.17	Scraper		103138



Ref.	Part description	Product code	
		C9G3EX004X	
		Feature	Part code
8.1	Knob		218E00A549
8.2	Knob spring		035036
8.3	Oven switch knob ring		218300E273
8.6	Switch spacer		103948
8.14	Oven encoder		050125
8.15	Oven switch		050126
8.16	Electronic thermostat		066220_26
8.17	Top + grill element	230V	062171004
8.18	Bottom element	230V	062170004
8.19	Lower element protection		4219G05Z
8.20	Bottom element support		1031844
8.21	Bottom element bar		51B9G07Z
8.22	Fan diffuser		47A9G06G
8.24	Complete oven fan left	220/240 V 50-60 Hz	079073
8.26	Fan element	230V	062168004
8.27	Clip		213031
8.28			213026
8.29	Fan motor support		51BFG01
8.30	Complete oven fan right	220/240 V 50-60 Hz	079049
8.31	Fan motor divider		4219G01G
8.32	Temperature sensor		107071



Ref.	Part description	Product code	
		C9G3EX004X	
		Feature	Part code
9.1	Electronic programmer	230 V 50 Hz	074149
9.2	Electronic programmer housing		094983
9.3	Electronic programmer mask		1031995
9.4	Knob		218E00A549
9.5	Knob spring		035036
9.6	Potentiometer knob ring		218300E273
9.7	Spacer		103948
9.8	Potentiometer		050095
11.1	Lamp holder		072032
11.2	Lamp	230 V 25 W	073103
11.3	Terminal block		051086
11.10	Cable	L=280 mm	055070
		L=400 mm	103862
11.11	Terminal block	16A - 2P	051036
11.16	Main wiring		1133038
11.16	Module wiring		1132489
11.17	PCB-Encoders connection		1132066
11.18	PCB control-module induction connection		1132065
11.19	PCB-PCB control connection		1132064
11.20	Cut-off thermostat	55°C	066224
11.37	Encoder wires	L=265 mm	1132593
11.38	Temperature sensor wires	L=785 mm	1132592
-	Instruction booklet	GB	1106817/GB
		GB	1106817/NL