



Product code:


C97TEX005A

Product: **Cooker**


Model: **EBS 965T MAA**

Product code	Serial No.	Product remark	Issue No.	Issue Date
C97TEX005A				October 2025



Key part information	
A	Auxiliary burner
SR	Semirapid burner
R	Rapid burner
DCC	Double Ring Compact burner




Ref.	Part description	Product code	
		C97TEX005A	
		Feature	Part code
1.5	Plug / Gommino		040041001
1.6	Screw / Vite		001352
2.1	Manifold / Tubo rampa		3429750001
2.2	Cooktop / Piano		331935001A
2.5	Cross bar manifold support / Staffa supporto rampa		51B9704
2.15	Pan-support / Griglia laterale		217867
2.16	Central pan-support / Griglia centrale		217868
2.30	Pot reducer / Griglia di riduzione		217733
3.1	Control panel / Frontalino		35C9701ADL
3.2	Towel rail handle / Maniglia corrimano		037424001




Ref.	Part description	Product code	
		C97TEX005A	
		Feature	Part code
4.2	Left oven insulation		030306
4.3	Right oven insulation		030312
4.4	Rear insulation left oven		030305
4.5	Rear insulation right oven		030313
4.6	Rear left support bracket		0941052SX
4.7	Rear right support bracket		0941052DX
4.8	Rear panel		4119701Z
4.9	Upper shelter		42197001Z
4.11	Panel rear spacer		094895.1
4.12	Right oven seal		053230
4.13	Left oven seal		053226
4.14	Door hinge (female)		063130
4.15	Tube retainer		531533
4.18	Shim		1032153A
4.19	Panel spacer		040102
4.20	Door panel right hinge		063172
4.21	Door panel left hinge		063173
4.23	Front panel		371V9701A
4.24	Inside panel		373V9G01Z
4.25	Side panel		36C9701A
4.27	Badge		081136
4.28	Left / Right rear trim		51B9703
4.31	Rear bracket		094412
4.32	Motor cross-piece		51B9702
4.33	Rear coupler		094886
4.35	Bottom rear panel		4219G03Z
4.36	Hob fixing left bracket		0941050SX
4.37	Hob fixing right bracket		0941050DX
4.38	Cooling fan conveyor		1031842
4.39	Fan motor	220-240 V 50-60 Hz	079092
4.40	Terminal block support		51B9E12
4.41	Lower element cover		45K96006Z
4.42	Left / Right support bracket		0941051
4.43	Lower shelter		4219G02Z
4.44	Anti-tilt bracket		094153
4.50	Body front panel		45B9701G
4.51	Oven cube (Right)		45094ES01G
4.52	Oven cube (Left)		450F7EM71G




Ref.	Part description	Product code	
		C97TEX005A	
		Feature	Part code
5.1	Left oven door glass / Vetro porta forno di sinistra		03297012
5.2	Door handle / Maniglia		037423001
5.3	Handle bush / Bussola maniglia		085108
5.4	Upper door trim		51BF710
5.5	Screw / Vite		001265
5.6	Middle inner glass		0313624
5.8	Rubber		040011
5.9	Left oven inner glass		0313608TH
5.11	Door hinge (male)		063163
5.12	Right oven door glass		03294012
5.13	Door handle / Maniglia		037422001
5.15	Upper door trim		51B9404
5.18	Right oven inner glass		0313855TH
5.19	Door hinge (male)		063184
5.20	Handle bush		085101















Ref.	Part description	Product code	
		C97TEX005A	
		Feature	Part code
6.1	Burner knob		218E00A548
6.2	Knob spring		035036
6.3	Burner knob ring		218300E273
6.4	Tap	Ø 0.33	106342G25
		Ø 0.34	106343G25
		Ø 0.43	106344G25
		Ø 0.64	106345G25
6.5	Tap fixing screw		001371
6.6	Tap bracket		094976
6.8A	Burner-cup	A	215537
6.8SR		SR	215538
6.8R		R	215539
6.9R	Burner head	R	068164
6.9SR		SR	068163
6.9A		A	068162
6.10A	Burner-cap	A	216172005A
6.10SR		SR	216173005A
6.10R		R	216174005A
6.12	Injector	Ø 0.72 - G25	101230
		Ø 0.94 - G25	101231
		Ø 1.25 - G25	101477
		Ø 1.45 - G25	101476
6.14	Elbow gasket		053024.1
6.15	Burner-cup	DCC	215540
6.17	Injector	DCC - Ø 1.50 - G20	101475
		DCC - Ø 1.00 - G30	101295
6.19	Front right inlet pipe	A	0291494
6.20	Rear right inlet pipe	SR	0291493
6.21	Central inlet pipe	DCC	0291492
6.22	Front left inlet pipe	R	0291491
6.23	Rear left inlet pipe	SR	0291477
6.25	Burner head	DCC	068165
6.26	Burner thermocouple	L=500 mm	107039
		DCC - L=450 mm	107057
6.27	Thermocouple nut	A-SR-R	214057
		DCC	214067
6.29	Gas connection		027018R
6.36	Burner-cap inside	DCC	216175005A
6.37	Burner-cap outside		216176005A



Ref.	Part description	Product code	
		C97TEX005A	
		Feature	Part code
7.1	Oven knob		218E00A549
7.2	Knob spring		035036
7.3	Left oven switch knob ring		218300E273
7.5	Spacer		103948
7.8	Thermostat		066157
7.14	Left oven Switch		050132
8.1	Lower element support		421F7104Z
8.2	Bottom element	230 V	062196004
8.3	Top + grill element		062182004
8.4	Fan motor	220-240 V 50-60 Hz	079091
8.6	Fan diffuser		47AF701G
8.9	Safety probe		107134
8.12	Fan element	230 V	062184004
8.13	Clip		213026
9.1	Shelf support		217859
9.3	Oven tray		48B6101G
9.4	Oven shelf		217823
9.5	Left telescopic runner / Slidind sinistra		1032126
9.6	Right telescopic runner / Slidind destra		1032125
9.;	T...e wxs r i		:74577



Ref.	Part description	Product code	
		C97TEX005A	
		Feature	Part code
7.1	Oven knob		218E00A549
7.2	Knob spring		035036
7.5	Spacer		103948
7.8	Thermostat		066157
7.15	Right oven switch		050134
7.16	Right oven switch knob ring		218300E273
8.9	Safety probe		107134
8.13	Clip		213026
8.14	Lower element support		421F4001Z
8.15	Bottom element	230 V	062195004
8.16	Top + grill element		062194004
9.1	Shelf support		217859
9.2	Rotisserie motor		079014
9.3	Rotisserie prong / Asta girarrosto		080026
9.4	Rotisserie support / Telaio supporto girarrosto		217870
9.5	Oven shelf / Griglia scaldapiatti		217869
9.10	Oven tray		48B9401G



Ref.	Part description	Product code	
		C97TEX005A	
		Feature	Part code
10.1	Electronic programmer housing		094983
10.2	Electronic programmer	230 V 50-60 Hz	074149
10.3	Display mask		1031995
11.1	Lamp holder		072026
11.2	Lamp	230 V 25 W	073103
11.3	Terminal block	40A 5P	051087
		16A 2P	051036
11.4	Cord / Cordoniera		054056
11.5	Burners ignition coil	220-240 V 50-60 Hz	082094
11.7	Igniter spring	SR-DU	035094
		DU-DCC	035139
11.8	Igniter	L=630 mm	084029
		L=900 mm	084036
		DCC-L=510 mm	084084
11.16	Wiring	Left oven	1133071
		Right oven	1133072
	Earth wiring		1133087
11.18	Ignition switches		105053
11.33	Control lamp cover	Transparent	073112
11.34	Control lamp	L=230 mm	073109
11.35	Control lamp adapter		1031739
11.36	Cut-off thermostat	65 °C	066186
		80 °C	066145
11.37	Wire fastener		052008
-	Instruction booklet	GB	1106808/GB
		NL	1106808/NL